



NOTE :- OIL INLET, OUTLET AND OIL INDICATOR AS PER MOUNTING POSITION

SD-100 = 6,8,10,12 INDEXING

VIEW FROM X